

Cohesive Sampler



Single Point Sampler for Cohesive Powders

The Cohesive Sampler is able to take a sample from a known point within the product.

- Single Point
- 316 stainless steel
- Suitable for sticky, cohesive powders

Operation

1. Insert sampler into product ensuring that the sample collecting chamber is in the closed position
2. At the correct sampling depth, turn the inner tube to expose the sample collecting chamber
3. Rotate the entire sampler through 360°. The scraper collects product and guides it into the sample collecting chamber.
4. Turn the inner tube to close the sample collecting chamber
5. Remove sampler
6. Pull out the inner tube and discharge the sample



Rotate the Whole sampler To take the Sample

Close the sampler and withdraw it from the product.

Rotate the inner core to open the sampler



QUOTE REQUEST ✓

BUY ONLINE ✓

Stock No.	Sample Volume	Length	Diameter
675 2015A05	5ml	1000mm	25mm
675 2015A10	10ml	1000mm	25mm
675 2015A25	25ml	1000mm	25mm